

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Kit Contents

| | Part No | Pcs |
|------------------------|----------|-----|
| Shock absorber 36PRCLB | KA131 | 2 |
| Sticker set Öhlins | | 1 |
| Tool pre-load adjuster | 03199-03 | 1 |
| Owners manual | 07241-02 | 1 |

👁 Note!

Please note that this image is a general representation of the product and may differ slightly from your product.

👁 Note!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

⚠ Warning!

Before installing this product, read the Öhlins Owner's Manual. The shock absorber/front fork/steering damper is an important part of your vehicle and will affect the stability.

Product for Kawasaki Street Line

KA 131

Mounting Instructions



MOUNTING INSTRUCTIONS

Warning!

It is advisable to have an Öhlins dealer install the shock absorber/front fork/steering damper.

Warning!

If working on a raised vehicle, ensure it is securely supported so that it will not tip.

Note!

Before mounting this product clean the vehicle thoroughly.

Note!

When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.

1

Put the motorcycle on a stand so the rear wheel is clear of the ground.

Warning!

Make sure the vehicle is securely supported so that it will not tip.

2

Loosen and remove the standard shock absorbers. See the motorcycle's Workshop manual.

3

Fit the Öhlins shock absorbers in the same position as the standard shock absorber.

Note!

Before installing the Öhlins shock absorber clean the vehicle thoroughly.

Note!

Lower the vehicle so that the suspension is slightly compressed before tightening the screws.

Caution!

Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber/front fork/steering damper when the suspension is fully compressed or extended.

4

Make sure that all removed parts are reinstalled in the same way as they were before the installation of the Öhlins shock absorber.

MOUNTING INSTRUCTIONS



ADJUSTMENTS

⚠ Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.

⚠ Warning!

The adjustable end eye/bracket must not be threaded out more than that the groove is fully visible beneath the lock nut. This is maximum length. After adjusting, make sure that the lock nut is tightened.



SET-UP DATA

Recommended set-up

Rebound 12 clicks
 Compression 2 clicks
 Spring Preload..... 23 mm

Spring

Part No. 00480-13
 Free spring length..... 230 mm

Shock absorber data

Length..... 347 (+7/-3) mm
 Stroke 92 mm

👁 Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI_KA131_1
 Issued 2017-01-01



© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB is prohibited.

Öhlins Racing AB
 Box 722
 S-194 27 Upplands Väsby, Sweden
 Phone +46 8 590 025 00
 fax +46 8 590 025 80



www.ohlins.com